




# Polaroid S10 Removing the backcover Replacement

Prerequisite Only

Written By: Christofer





## TOOLS:

- [iFixit Opening Picks set of 6](#) (1)
  - [Metal Spudger Set](#) (1)
-

## Step 1 — Removing the backcover



- Place an opening pick between the volume button and the back cover.
- ⓘ More than one pick may be needed but avoid placing more than two in the space.
- ⚠ Excessive force on the pick will break the volume button.
- Carefully use the metal spundger to remove the back cover.
- ⓘ A plastic snap noise is normal due to the tabs on the back cover.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-08-28 08:48:12 PM.